

# Compressor Capacity: Midpoint vs Dewpoint

## Technical Bulletin

Product: Refrigerant Blends with glide (R-400 series)

Bulletin#: 03 rev 0.0

Application: Refrigeration

**Background:** Zeotropic blended refrigerants exhibit glide due to the different properties of the blended refrigerants. To get the fullest benefit from the new generation of refrigerants it is important to understand the impact of glide.

This is especially true when sizing compressors for refrigerants with glide such as Solstice® N40 (R-448A). It is important to understand the difference between midpoint<sup>1</sup> and dewpoint compressor capacities.

This bulletin will describe how to properly use midpoint when sizing compressors.

**Problem:** Compressors can be sized by selecting either midpoint or dewpoint in compressor selection software.

By using dewpoint, the compressor is sized using the saturated vapor temperature at the evaporator pressure. Because refrigerants with glide have an average coil temperature significantly lower than the dewpoint, the use of dewpoint will lead to an incorrectly-sized compressor.

If dewpoint temperature is used, compressor sizing programs will show an evaporator capacity lower than what the compressor actually provides. This can lead to oversizing of compressors, extra cost, and possible system issues.

Refrigeration designers are accustomed to sizing compressors using the dewpoint temperature. This is because legacy refrigerants did not have glide and so the dewpoint and midpoint temperature were equal. Using dewpoint with legacy refrigerants had no effect on the compressor capacity.

**Resolution:** Select midpoint in compressor sizing programs when using refrigerants with glide.

Selecting midpoint is important because it will reflect the actual refrigeration impact of the refrigerant on the product being cooled. With Solstice N40 (R-448A), choosing dewpoint would give a false 5°F rise in the temperature of the evaporator coil.

The table on the right gives the relative impact of choosing midpoint for R-448A and R-404A.

Bulletin 04 will discuss the value of using net refrigeration effect when sizing compressors.



### Gain in compressor capacity when using midpoint

| Usage              | Capacity Impact    |
|--------------------|--------------------|
| R-448A Medium temp | +4.4%              |
| R-448A Low temp    | +6.6%              |
| R-404A Medium temp | +0.1% <sup>2</sup> |
| R-404A Low temp    | +0.8% <sup>2</sup> |

### Selecting midpoint will:

- Give actual capacities to allow for the correct sizing of compressors and equipment
- Prevent oversizing of equipment and result in a reduction in capital costs
- Give an accurate performance comparison of single component refrigerants versus refrigerants with glide such as Solstice N40 (R-448A)

<sup>1</sup> The term midpoint is used for simplicity. The actual coil temperature will be nominally impacted by system parameters. Some programs use the term "mean" instead of midpoint.

<sup>2</sup> R-404A has minimal glide which is reflected in the nominal impact of using midpoint with R-404A.

Please contact Honeywell Technical Services for a more detailed description of selecting midpoint in compressor sizing programs.

### For more information:

Technical Support Team

800-631-8138

[www.honeywell-refrigerants.com](http://www.honeywell-refrigerants.com)

### Honeywell Refrigerants

115 Tabor Road

Morris Plains, NJ 07950

Although Honeywell International Inc. believes that the information contained herein is accurate and reliable, it is presented without guarantee or responsibility of any kind and does not constitute any representation or warranty of Honeywell International Inc., either expressed or implied. A number of factors may affect the performance of any products used in conjunction with user's materials, such as other raw materials, application, formulation, environmental factors and manufacturing conditions among others, all of which must be taken into account by the user in producing or using the products. The user should not assume that all necessary data for the proper evaluation of these products are contained herein. Information provided herein does not relieve the user from the responsibility of carrying out its own tests and experiments, and the user assumes all risks and liabilities (including, but not limited to, risks relating to results, patent infringement, regulatory compliance and health, safety and environment) related to the use of the products and/or information contained herein.



Solstice is a registered trademark of Honeywell International Inc.

FP REF 1788 | September 2017 | v3

© 2017 Honeywell International Inc. All rights reserved.